


PV4 electro-pumps



Pump with thermoplastic delivery head

Pump with metal delivery head

Part No.	Description
7	Sleeve
7.1	Spacer
7.2	Spacer
7.8	Bearing spacer
11	Bearing
16.1	Cover plate
16.2	Suction plate
21	Delivery head
24	Shaft
28	Turbine
29	Diffuser
39	Tube
2.39	Tube clamping nut
3.39	Tube clamping washer
62	Bearing bush
67	Ferrule

Part No.	Description
68	Inlet filter
69	Protective grille
71	Revolving joint
2.71	Revolving joint screw
72	Spacer ring
81	O ring seal
83	Screw
3.83	Washer
84	Turbine screw
3.84	Brake washer
88	Coupling sleeve
2.88	Coupling sleeve screw
90	Draining plug
95	Pin
101	Motor